

SAFETY MATTERS CONSTRUCTION SERIES



**ELECTRICAL
INCIDENTS**

Power Tool Safety Tips

- Never carry a tool by the cord.
- Never yank the cord to disconnect it from the receptacle.
- Keep cords away from heat, oil, and sharp edges (including the cutting surface of a power saw or drill).
- Disconnect tools when not in use, before servicing, and when changing accessories such as blades, bits, etc.
- Avoid accidental starting. Do not hold fingers on the switch button while carrying a plugged-in tool.
- Use gloves and appropriate safety footwear when using electric tools.
- Store electric tools in a dry place when not in use.
- Do not use electric tools in damp or wet locations unless they are approved for that purpose.
- Keep work areas well lit when operating electric tools.
- Ensure that cords from electric tools do not present a tripping hazard.
- Remove all damaged portable electric tools from use and tag them: "Do Not Use."
- Use Double-Insulated Tools.



Safety Matters Construction Series information is extracted directly from OSHA safety materials. For additional information consult www.OSHA.gov