

## ATTACHMENT 9 – GENERATOR SPECIFICATIONS

<b>Generator</b>	<b>Transfer Switches</b>
600kW Generac	ATS Switch SP-DP-LS-100 amp
	Tenant 100 AMP Serves Life Safety systems
	ATS Switch-LS-SC NYSIF 60 Amp Life Safety loads
	ATS Switch NYSIF 400 Amp for existing ATS-1-2-3 & 1A
	ATS Switch Tenant 100 AMP serves Life Safety systems
	ATS Fire Pump and Jockey Pump 600 AMP
	ATS-SP-A 800 AMP serves Elevator car 1/ New chiller /SP-2A Panel 2nd floor
	Generator Switchboard SB-SP-M 1200 AMP Tenant
	ATS=SP-B 1200 AMP Serves panel # 18, 28 & UPS
500kW Generac	MTS-1 100 AMP Serves Cooling Tower 1 from ATS # 8
	MTS-2 100 AMP Serves cooling tower 2 from ATS # 8
	MTS-3 100 AMP Serves cooling tower 3 from ATS # 8
	ATS-4 1200 AMP Serves 12th floor low rise cars 1-2-3-4
	ATS -5 200 AMP Serves 14th floor land room
	ATS-6 1200 AMP Serves elevator MER Cars 5-6-7-8
	ATS-7 100 AMP Serves EPD Panel emergency loads
	ATS-9 200 AMP SERVES 16th floor MER / 17th floor AC Loads / 100 AMP Panel HM-17